



**Flow reset:**

1. press 'Alarm reset' 2sec long.
2. connect NC push button series flow switch.

Remark: Auto-man เป็น Selector switch on-off-on

Title:	<b>Booster pump.</b>	Electronic pump controller:	<b>B2-fw</b>
Drawn by:	SMK Engineering Ltd., Part.	Revision:	1
Date:	15/12/2554	Sheet of:	1